

Thank you for purchasing our equipment. Please read this manual carefully and heed the safety warnings and instructions before installing, using or repairing the equipment. This will ensure not only the protection of persons, but also the long life of the equipment.

TECHNICAL PARAMETERS

Power	1500W
Power supply	230V/50Hz
IP coverage	IP20
Dimensions	16,5x11,5x24cm
Cable length	1,5m
Weight	1.1kg
Fan mode	fan for air circulation, low heating, high heating

The device has overheating protection.

DESCRIPTION OF EQUIPMENT

1. Heating point controller
2. Thermostat controller
3. Safety switch in case of tipping

SAFETY NOTICE

- If the safety instructions are ignored, the manufacturer is not liable for any damage.
- If the power cord is damaged, it must be replaced by the manufacturer, its service representative or similarly qualified person to avoid potential hazards.
- Never carry the appliance by pulling the power cord and make sure that the cord cannot get stuck.
- The appliance must be placed on a stable and level surface.
- Never leave the appliance on unattended.
- This appliance may only be used in the home for the purpose for which it was manufactured.
- This appliance must not be used by children under 8 years of age. This appliance may be used by persons over 8 years of age and persons with reduced physical, sensory or mental abilities or lack of experience and knowledge only if they are supervised or have been instructed in the safe use of the appliance and understand the possible risks. Children must not play with the appliance. Keep the appliance and cord out of the reach of children under 8 years of age. Cleaning and maintenance cannot be carried out by children who are under 8 years of age and unsupervised.
- To protect yourself from electrical shock, do not immerse the power cord, plug or appliance in water or other liquids.
- To avoid overheating, do not cover the device with anything.
- Some parts of this product can become very hot and cause burns. Extreme care should be taken in the presence of children or vulnerable persons.
- Particular care should be taken in the presence of children or vulnerable persons.
- Do not use this appliance with a programmer, timer, separate remote control system or any device automatically turns on the heater as there is a risk of fire if the appliance is covered or improperly positioned.
- Do not use this heater near a bathtub, shower or swimming pool.
- No beams, joists or trusses should be cut or cut when installing the unit.
- Please do not place the unit near curtains or other flammable materials. This could cause a fire.
- Air discharge regulations need to be met.
- Under no circumstances should the unit be covered with insulation or other similar material.
- The heater must not be placed directly under the socket.
- The heater should be installed so that switches and other controls cannot be touched directly from the bath or shower.
- WARNING: The heater must not be used if the ceramic panels are damaged.
- WARNING: This heater must not be used with a room temperature control device. Do not use this heater in small rooms when occupied by persons who are unable to leave the room independently unless supervision is provided at all times.
- At the end of the equipment's service life, dispose of it in a designated place. The equipment does not belong in normal household waste.



BEFORE FIRST USE

- Place the appliance on a flat, stable surface and ensure a minimum of 10cm clearance around the appliance.
- A slight odour may occur on first use, which is quite common. Ensure sufficient ventilation.

USE

- Insert the plug into an electrical socket.
- Use the heating point controller to set the desired heating mode.
- Switch on the appliance by turning the speed control clockwise to the desired position.
- The oscillation function can only be used in conjunction with the highest heating mode.

CLEANING AND MAINTENANCE

- Always unplug the iron and let it cool completely before cleaning.
- Clean the outside with a damp cloth. Never use coarse or abrasive cleaners, wire cloth or a scraper, which will damage the appliance. Do not immerse in water or other liquids.
- Clean the air inlet and outlet regularly with a vacuum cleaner and remove dust.

The product has been issued with a CE declaration of conformity in accordance with the applicable regulations.
On request from the manufacturer: info@solight.cz, or downloadable from www.solight.cz/en.



SOLIGHT

Solight Holding, s.r.o., Na Brně 1972, Hradec Králové 500 06, Czech Republic.